

# Chapter 10

## APPROXIMATIONS FOR ANALOG FILTERS

### 10.8 Analog-Filter Transformations

---

Copyright © 2005 Andreas Antoniou  
Victoria, BC, Canada  
Email: [aantoniou@ieee.org](mailto:aantoniou@ieee.org)

July 14, 2018

# Analog-Filter Transformations

- Given a normalized transfer function obtained by any one of the classical analog-filter approximations, a *denormalized* lowpass, highpass, bandpass, or bandstop transfer function can be obtained by applying a transformation of the form

$$H_X(\bar{s}) = H_N(s) \Big|_{s=f_X(\bar{s})}$$

where  $f_X(\bar{s})$  is one of the four standard *analog-filter transformations*.

## Analog-Filter Transformations *Cont'd*

Standard forms of  $f_X(\bar{s})$

Type	$f_X(\bar{s})$
LP to LP	$\lambda\bar{s}$
LP to HP	$\lambda/\bar{s}$
LP to BP	$\frac{1}{B} \left( \bar{s} + \frac{\omega_0^2}{\bar{s}} \right)$
LP to BS	$\frac{B\bar{s}}{\bar{s}^2 + \omega_0^2}$

# Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function  $H_N(s)$  with passband and stopband edges  $\omega_p$  and  $\omega_a$ .

# Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function  $H_N(s)$  with passband and stopband edges  $\omega_p$  and  $\omega_a$ .
- A denormalized lowpass transfer function can be obtained as

$$H_{LP}(\bar{s}) = H_N(s) \Big|_{s=\lambda\bar{s}}$$

# Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function  $H_N(s)$  with passband and stopband edges  $\omega_p$  and  $\omega_a$ .
- A denormalized lowpass transfer function can be obtained as

$$H_{LP}(\bar{s}) = H_N(s) \Big|_{s=\lambda\bar{s}}$$

- By letting  $\bar{s} = j\bar{\omega}$  and  $s = j\omega$ , we get

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

Therefore, the gain (loss) of the denormalized lowpass filter is equal to the gain (loss) of the normalized lowpass filter provided that  $\omega = \lambda\bar{\omega}$ .

...

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the  $j\omega$  axis of the  $s$  plane map onto points on the  $j\bar{\omega}$  axis of the  $\bar{s}$  plane.

In particular,

...

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the  $j\omega$  axis of the  $s$  plane map onto points on the  $j\bar{\omega}$  axis of the  $\bar{s}$  plane.

In particular,

- the origin of the  $s$  plane maps onto the origin of the  $\bar{s}$  plane,

...

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the  $j\omega$  axis of the  $s$  plane map onto points on the  $j\bar{\omega}$  axis of the  $\bar{s}$  plane.

In particular,

- the origin of the  $s$  plane maps onto the origin of the  $\bar{s}$  plane,
- point  $j\omega_p$  of the  $s$  plane maps onto point  $j\bar{\omega}_p = j\omega_p/\lambda$  of the  $\bar{s}$  plane,

...

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the  $j\omega$  axis of the  $s$  plane map onto points on the  $j\bar{\omega}$  axis of the  $\bar{s}$  plane.

In particular,

- the origin of the  $s$  plane maps onto the origin of the  $\bar{s}$  plane,
- point  $j\omega_p$  of the  $s$  plane maps onto point  $j\bar{\omega}_p = j\omega_p/\lambda$  of the  $\bar{s}$  plane,
- point  $j\omega_a$  of the  $s$  plane maps onto point  $j\bar{\omega}_a = j\omega_a/\lambda$  of the  $\bar{s}$  plane, and

...


$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the  $j\omega$  axis of the  $s$  plane map onto points on the  $j\bar{\omega}$  axis of the  $\bar{s}$  plane.


In particular,

- the origin of the  $s$  plane maps onto the origin of the  $\bar{s}$  plane,
- point  $j\omega_p$  of the  $s$  plane maps onto point  $j\bar{\omega}_p = j\omega_p/\lambda$  of the  $\bar{s}$  plane,
- point  $j\omega_a$  of the  $s$  plane maps onto point  $j\bar{\omega}_a = j\omega_a/\lambda$  of the  $\bar{s}$  plane, and
- infinity of the  $s$  plane maps onto infinity of the  $\bar{s}$  plane.

# LP-to-LP Transformation – Mapping Properties



# LP-to-LP Transformation – Graphical Illustration



# Lowpass-to-Highpass Transformation

- The LP-to-HP transformation follows the pattern of the LP-to-LP transformation.

# Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left( \bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

# Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left( \bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

- By letting  $\bar{s} = j\bar{\omega}$  and  $s = j\omega$ , we get

$$|H_{BP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = \frac{1}{B} \left( j\bar{\omega} + \frac{\omega_0^2}{j\bar{\omega}} \right)}$$

# Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left( \bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

- By letting  $\bar{s} = j\bar{\omega}$  and  $s = j\omega$ , we get

$$|H_{BP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = \frac{1}{B} \left( j\bar{\omega} + \frac{\omega_0^2}{j\bar{\omega}} \right)}$$

- Therefore, the gain (loss) of the denormalized bandpass filter is equal to the gain (loss) of the normalized lowpass filter provided that

$$\omega = \frac{1}{B} \left( \bar{\omega} - \frac{\omega_0^2}{\bar{\omega}} \right)$$

...

$$\omega = \frac{1}{B} \left( \bar{\omega} - \frac{\omega_0^2}{\bar{\omega}} \right)$$

- Solving for  $\bar{\omega}$ , we get

$$\bar{\omega} = \begin{cases} \omega_0 & \text{if } \omega = 0 \\ \pm \bar{\omega}_{p1}, \pm \bar{\omega}_{p2} & \text{if } \omega = \pm \omega_p \\ \pm \bar{\omega}_{a1}, \pm \bar{\omega}_{a2} & \text{if } \omega = \pm \omega_a \end{cases}$$

where

$$\bar{\omega}_{p1}, \bar{\omega}_{p2} = \mp \frac{\omega_p B}{2} + \sqrt{\omega_0^2 + \left( \frac{\omega_p B}{2} \right)^2}$$

$$\bar{\omega}_{a1}, \bar{\omega}_{a2} = \mp \frac{\omega_a B}{2} + \sqrt{\omega_0^2 + \left( \frac{\omega_a B}{2} \right)^2}$$

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,
  - the origin of the  $s$  plane maps onto point  $j\omega_0$  of the  $\bar{s}$  plane,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- the origin of the  $s$  plane maps onto point  $j\omega_0$  of the  $\bar{s}$  plane,
- points  $\pm j\omega_p$  of the  $s$  plane map onto points  $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$  of the  $\bar{s}$  plane,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- the origin of the  $s$  plane maps onto point  $j\omega_0$  of the  $\bar{s}$  plane,
- points  $\pm j\omega_p$  of the  $s$  plane map onto points  $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$  of the  $\bar{s}$  plane,
- points  $\pm j\omega_a$  of the  $s$  plane map onto points  $\pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2}$  of the  $\bar{s}$  plane, and


- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$


- In effect,

- the origin of the  $s$  plane maps onto point  $j\omega_0$  of the  $\bar{s}$  plane,
- points  $\pm j\omega_p$  of the  $s$  plane map onto points  $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$  of the  $\bar{s}$  plane,
- points  $\pm j\omega_a$  of the  $s$  plane map onto points  $\pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2}$  of the  $\bar{s}$  plane, and
- $\pm\infty$  of the  $s$  plane maps onto  $\mp\infty$  of the  $\bar{s}$  plane.

# LP-to-BP Transformation – Mapping Properties



# LP-to-BP Transformation – Graphical Illustration



# Lowpass-to-Bandstop Transformation

- The LP-to-BS transformation follows the pattern of the LP-to-BP transformation.

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
  - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
  - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
  - The maximum passband loss,  $A_p$ , and minimum stopband loss,  $A_s$ , of the normalized filter are preserved in the denormalized filter.

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
  - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
  - The maximum passband loss,  $A_p$ , and minimum stopband loss,  $A_s$ , of the normalized filter are preserved in the denormalized filter.
  - Parameter  $\lambda$  scales the passband or stopband edge of a denormalized lowpass or highpass filter relative to the passband or stopband edge of the normalized filter.

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
  - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
  - The maximum passband loss,  $A_p$ , and minimum stopband loss,  $A_s$ , of the normalized filter are preserved in the denormalized filter.
  - Parameter  $\lambda$  scales the passband or stopband edge of a denormalized lowpass or highpass filter relative to the passband or stopband edge of the normalized filter.
  - Parameters  $\omega_0$  and  $B$  scale the location and passband or stopband width of a denormalized bandpass or bandstop filter.

## Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
  - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
  - The maximum passband loss,  $A_p$ , and minimum stopband loss,  $A_s$ , of the normalized filter are preserved in the denormalized filter.
  - Parameter  $\lambda$  scales the passband or stopband edge of a denormalized lowpass or highpass filter relative to the passband or stopband edge of the normalized filter.
  - Parameters  $\omega_0$  and  $B$  scale the location and passband or stopband width of a denormalized bandpass or bandstop filter.
- The transformations are used in Chap. 12 to design recursive lowpass, highpass, bandpass, and bandstop filters that would satisfy arbitrary prescribed specifications.

*This slide concludes the presentation.  
Thank you for your attention.*